

Greenfix Newt Barrier Installation



Dig a trench 300mm deep and 150mm wide leaving spoil to one side of the trench

Use 1.2m x 50mm wooden posts driven into the ground to secure the Newt Barrier film.

Secure the roll of Newt Barrier film to the posts using suitable galvanised nails and penny washer type washers or wooden battens to help prevent tearing and damage at the fixing points.

Backfill the trench once the barrier is fully secured.

The life span of this product is totally dependant on the weather conditions at the location that it is installed and the method of installation. Windy conditions may cause the product to fail prematurely through tearing and shredding.

The specification presented above is to the best of our knowledge, true and accurate. Greenfix Soil Stabilisation and Erosion Control Limited (GSSEC) reserve the right to change any specification without prior notice. GSSEC cannot guarantee or offer warranty on products, unless agreed to in writing for specific conditions or for performance as the manner of handling, use and installation are beyond our control. We will not be liable for damages or losses, direct or indirect, of our GSSEC Range of Products due to the above reasons. All comparative data was correct at time of print. E&OE.