

## Greenfix Coir Rolls Installation Instructions

- Part drive into water margin, 4 stakes per Greenfix Bio-roll.
- Stakes are typically 1.2 m long x 65 mm average diameter quarter cut chestnut stakes at 0.8m centers.
- Place Greenfix Bio-rolls into position, embankment side of fixing stakes with 100mm of roll above water level.
- Tie ends of Greenfix Bio-rolls together using suitable twine or wire. Fully drive in stakes to the top of the Bio-roll.
- Tie Greenfix Bio-rolls onto stakes using suitable twine or wire.
- Backfill where necessary to rear of Greenfix Bio-rolls. Additional planting can be incorporated into the backfill material.
- Consideration should be given to bird protection netting if necessary.

