

Greenfix NF-100 Newt Barrier Film Installation Instructions

Dig a trench 300mm deep and 300mm wide leaving spoil to one side of the trench

Use 900mm x 50mm wooden posts driven into the ground leaving 600mm exposed above the surface to secure the Newt Barrier film

Secure the roll of Newt Barrier film to the posts using galvanised nails and washers. Fold the Newt Barrier film to the top of the post, at the mid point of the post and at the bottom of the post.

Once the barrier is fully secured fold the excess Newt Barrier film into the trench and backfill the trench.

For further guidance see drawing below

